



CREATIVEUTVGRAPHICS.COM

Decals for your Custom Needs



IMPORTANT:

- DO NOT apply on wet or dirty surface.
- DO NOT apply in temperatures below 60° F whenever possible.
- DO NOT expose to humid conditions for 48 hours after installation.
- DO NOT remove the clear transfer tape from parts 1L, 1R, 4R & L4 until they are installed.
- Use a heat gun preferably at max 250° F and apply pressure with a rubber roller brayer if possible.
- Re-apply heat after 48 hours of installation.
- For more detailed instructions please go to: <http://www.creativeutvgraphics.com/installation-guide-videos>



Tools Required:



Rubber Roller Brayer

Squeegee for vinyl application

Heat Gun

Note:

Tools can be found in major craft and hardware stores.

